
MAC 520 DAB

User Manual
-Navigation software-



MAC
AUDIO

Thank you for choosing our product as your navigator. Start using your device right away. This document is the detailed description of the navigation software. You can easily discover the software while you are using it; however, we still recommend that you read this manual to fully understand the screens and features.


Table of contents


Getting started	4
Startup screen: the Navigation menu	6
Find menu.....	7
Navigating to an address	8
Navigating to a place of interest	10
An example of navigating to a place of interest.....	12
The map screen.....	14
„More’ menu”.....	15
Settings menu.....	16
Copyright note	18


Getting started




When using the navigation software for the first time, an initial setup process starts automatically. Do as follows:

☞ Read the Software and Database End User Licence Agreement, and tap  if you agree with the terms of use.



☞ You are now asked whether you allow the software to collect usage information and GPS logs that may be used for improving the application and the quality and coverage of maps. Tap  to allow the anonymous statistics or disable this function.


☞ The Configuration wizard starts in the selected language. Tap  to continue.


☞ Select the voice guidance language profile. If your preferred language does not appear on the screen, scroll the list for other available profiles. Tap any item in the list for a short voice sample. Tap  to confirm your selection, and proceed to the next page.

The application starts.



Getting started



☞ Set your preferred time format and units. Tap  to confirm your preferences.

☞ Set your preferred route planning options. Tap  to confirm your preferences.

☞ If an Internet connection is available, the application will check your licenses for the connected services. This may take a few seconds. When finished, you will be asked to activate these services. You can choose to activate them later or do it right away. Tap

 , enter the activation code and tap  again to activate your product.

☞ The initial setup is now complete. Tap .

The application starts.

Startup screen: the Navigation menu



After the initial setup, and whenever the software is started, the Navigation menu appears. You have the following options:

- Find



• Tap **Find** to select your destination by entering an address or selecting a place of interest, a location on the map or one of your Favourite destinations. You can also look up your recent destinations from the Smart History or by entering its coordinate. When internet connection is available, Google Local Search can be a further help to find your destination.
- Find

• Tap **Find** to select your destination by entering an address or selecting a place of interest, a location on the map or one of your Favourite destinations. You can also look up your recent destinations from the Smart History. When internet connection is available, Google Local Search can be a further help to find your destination.
- My Route




• Tap **My Route** to display the route parameters. You can view the route in its full length on the map. You can also perform route-related actions such as editing or cancelling your route, setting a start point for the route, picking route alternatives, avoiding parts of the route, simulating navigation or adding the destination to your Favourites.
- More...


• Tap **More...** to customise the way the navigation software works, simulate demo routes, or to run some additional applications.
- Show Map**









• Tap **Show Map** to start navigating on the map.

- Tap  to start Voice Recognition.
- Tap  to stop navigation and exit the software.


Find menu





In the Navigation menu, tap  **Find**. The Find menu provides you with the following options:


- Tap  **Find Address** to specify an address as your destination.
- Tap  **Find Places** to select a place of interest as your destination.
- Tap  **Local Search** to use the Google Local Search service.
- Tap  **Favourites** to choose from the list of your favourite destinations.
- Tap  or  to navigate to the recent destination that is shown on the button.
- Tap  **History** to choose from the list of all recent destinations.
- Tap  **More** for other search methods.

Navigating to an address







In the Navigation menu, tap , then tap . By default, the screen proposes the city or town where you are located.



 If needed, change the country. Tap the button showing the name of the country.

1. Use the keyboard to enter the name of the country.
2. After entering a couple of characters, the list of countries that match the entered string appears. Tap the country of your choice.

 If needed, change the city/town. Tap the button showing the name of the city/town, and use the keyboard to enter a part of its name. As you enter letters, the most likely city/town name is always shown in the input field. You have the following options:

- Tap  to select the city/town that is offered in the input field.
- Tap  to correct your entry.
- Tap  to browse the list of city/town names matching your input. Select a city/town from the list.

Navigating to an address



👉 Enter the street name:

1. Tap **<Street Name>**.
2. Use the keyboard to enter a part of the street name.
3. Tap **✓ Done** to select the street that is offered in the input field or **☰ Results** to browse the list of all streets matching your input. Select a street from the list.


👉 Enter the house number:

1. Tap **<House Number>**.
2. Use the keyboard to enter the house number.
3. Tap **✓ Done** to finish entering the address.



👉 The map appears with the selected destination in the middle. Tap another map location if necessary, then tap **✓ Next** to confirm the destination.





👉 After a short summary of the route parameters, the map appears showing the entire route. Wait for a few seconds or tap **➡ Go!** and start navigating.


Navigating to a place of interest



Menu

On the Map screen, tap  to return to the Navigation menu. In the Navigation menu, tap . You are offered the following preset search categories:

- Tap  **Petrol Station Along Route** to get a list of petrol stations along the route or if it is not available, around your current position or your last known position.
- Tap  **Parking At My Destination** to get a list of parking lots near the destination or if it is not available, around your current position or your last known position.
- Tap  **Restaurant Along Route** to get a list of restaurants along the route, around your current position or your last known position.
- Tap  **Accommodation At My Destination** to get a list of accommodation near the destination, around your current position or your last known position.

You can also tap  and search for a place by entering its name.

If none of the above is appropriate, tap  to find a place of interest at the following locations:

Around Here

- Tap **Around Here** to search around the current position or if it is not available, around the last known position.

In a City

- Tap **In a City** to search for a place within a selected city or town.


**Around
Destination**

- Tap **Around Destination** to search for a place around the destination of the active route.

**Along
Route**

- Tap **Along Route** to search along the active route, and not around a given point. This is useful when you search for a later stopover that results in a minimal detour only, such as searching for upcoming petrol stations or restaurants.

An example of navigating to a place of interest





Example: To find a park around your destination, do as follows (starting from the Navigation menu):





The list of place categories appears. Tap  or slide your finger to browse the list,




and tap  to browse the whole category, or tap  to narrow down your search.

Tap any of the list items.

Check the details and the location of the place, and then tap .

After a short summary of the route parameters, the map appears showing the entire route. Wait for a few seconds or tap  and start navigating.


The Map screen




The Map screen is the most important and frequently used screen of the software. The Vehimarker (a blue arrow by default) represents your current position, and the orange line shows the recommended route. There are screen buttons and data fields on the screen to help you navigate. During navigation, the screen shows route information.

- At the top of the screen, you see your heading and the house numbers on left and right if you have not selected a route destination. When navigating a route, you see the next manoeuvre and the next street/road on your route. Tap either of them to open the route itinerary.



- Tap  to open the Quick menu with a selection of functions that are useful during navigation.
- Tap the map anywhere to explore the map around your current position. Additional map control buttons appear.





- Tap  to open three data fields on the map. Tap any of them to suppress the others. The default values for navigation (you can change them in Map settings):
 - the remaining distance to the destination,
 - the estimated time of the arrival at the destination, and
 - the remaining time of the trip.



- Tap  to open the Navigation menu.







,More' menu





The ,More' menu provides you with various options and additional applications. In the

Navigation menu, tap





- 
 Settings : Fine-tune route planning options, change the look of the Map screen, turn on or off warnings, or restart the Configuration wizard, etc.
- 
 Updates and Extras : Visit www.naviextras.com to get additional content, such as new maps or 3D landmarks and useful applications.
- 
 Picture Viewer : Access the Picture Viewer.
- 
 Clothing : Access travel applications: the unit converter, the clothing size converter or country information.
- 
 Fuel Consumption : Access other useful applications: the calculator, the fuel and maintenance monitor, sunrise and sunset information or the trip and track log monitor.
- 
 Help : Run the Demo to watch sample route simulations to see how navigation works, read the Software and Database End User License Agreement, or check the map and other contents of the application.







Settings menu










More...



In the Navigation menu, tap  More..., then tap  Settings. The Settings menu provides you with the following options (scroll the list to see all):

-  **Sound and Warnings**: Adjust the different sound volumes, change the voice guidance profile, or enable and set up warnings.
-  **Customise Quick Menu**: Change the function buttons in the Quick menu of the Map screen.
-  **Lorry**: Before selecting one of the Lorry profiles as the Vehicle type used in route calculation, set up the editable lorry attribute profile with the parameters of your lorry. These parameters will be used in route calculation.
-  **Traffic**: You can adjust traffic related settings such as using preloaded statistical or online traffic, or select whether to take traffic events into consideration when calculating the route.
-  **Route Settings**: Select the type of vehicle you are driving, the road types used in route planning, and the route planning method.
-  **Map settings**: Adjust map related settings: change the daytime and night colour schemes, change the default zoom level, switch between 2D and 3D map, suppress buildings or change the Vehimarker.

-  **Visual Guidance**: Adjust how the software helps you navigate with different kinds of route related information on the Map screen.
-  **Display**: Turn the menu animations on or off, select a different skin for the application, adjust the display backlight.
-  **Regional**: Change the program language, the time format, units or the time zone.
-  **Trip Monitor**: Turn the automatic trip or track log saving on or off, check the current size of the trip database.
-  **Log Collection**: The application collects usage information and GPS logs that may be used for improving the application and the quality and coverage of maps. Here you can enable or disable collecting these logs.
-  **Start Configuration Wizard**: Modify the basic software parameters set during the initial setup process.
-  **Reset to Defaults**: Delete all saved data and reset all settings to their factory defaults.

Copyright note

The product and the information contained herein are subject to change without prior notification. This manual may not, in whole or in part, be reproduced or transmitted in any form either electronically or mechanically, including photocopying and recording, without the express written consent of the software.

© 2017 - Mac Audio

Data Source © 2006-2013 Tele Atlas. All rights reserved. This material is proprietary and the subject of copyright protection, database right protection and other intellectual property rights owned by Tele Atlas or its suppliers. The use of this material is subject to the terms of a license agreement. Any unauthorised copying or disclosure of this material will lead to criminal and civil liabilities.

All rights reserved.

MAC AUDIO

Lise-Meitner-Str. 9 • D-50259 Pulheim • Germany
Tel. +49 (0) 2234 807-0 • Fax +49 (0) 2234 807-399
www.mac-audio.de